


3. Hang the TV onto the Wall Plate




Tighten the bottom bolts to secure the adapter brackets to the wall plate.

- Maintenance**
- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
 - Please contact customer support/service if you have any questions.






INSTALLATION MANUAL

Fixed Wall Mount



CAUTION: DO NOT EXCEED RATED LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

18015	 200x200/300x300 400x200/400x400	 55" MAX	 40kg (88lbs) RATED
--------------	--	---	---


NOTE: Read the entire instruction manual before you start installation and assembly.

⚠ WARNING

- This mounting bracket was designed to be installed and utilised **ONLY** as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



wall plate (x1)
A




adapter bracket (x2)
B




bubble level(x1)
C


Package M




M6x30 (x4)
M-A



M8x30 (x4)
M-B




D8 washer (x4)
M-C




big spacer (x4)
M-D


Package W



ST6.3x55 (x5)
W-A







concrete anchor (x5)
W-B




D6 washer (x5)
W-C

1. Solid Brick and Concrete Mounting




Mark the exact location of mounting holes



Drill pilot holes





Screw the wall plate onto the wall



⚠ WARNING

Please verify that the supporting surface will safely support the combined weight of the equipment, all attached hardware and components.

2. Installing the Adapter Brackets



- Note:** Choose appropriate screws, washers and spacers (if necessary) according to the type of screen.
- Position the adapter brackets as close as possible to the center of the TV.
 - Screw the adapter brackets onto the TV.

⚠ Tighten all screws but do not over tighten.